

其余
FAN RELAY
INJECTION POWER RELAY
LIGHTS RELAY
MAIN SWITCH
SPEED SENSOR
PICK UP
THE CUP MUST COVER THE CONNECTOR COMPLETELY
ECU
INJECTOR
LAMBDA SENSOR
WATER TEMP SENSOR
OIL PRESS SENSOR
IGNITION COIL
REAR LAMP
RIGHT REAR TURN INDICATOR
FUEL PUMP MODULE
HORN
FAN
FLASHER
VOLTAGE REGULATOR
PLASTIC CLAMP
JUMPER
SIDE STAND SWITCH
STARTER RELAY
DIAGNOSTIC
CHASSIS GROUND
POSITIVE BATTERY
REAR LICENSE PLATE LIGHT
EXTERNAL TEMP SENSOR
FRONT STOP SWITCH
MODE SWITCH
ECU MAP SWITCH
START SWITCH
LIGHT SWITCH
TURN SWITCH
HORN SWITCH
REAR STOP SWITCH
LEFT FRONT TURN INDICATOR
RIGHT FRONT TURN INDICATOR
POSITION LAMP
HEADLAMP
DASHBOARD
DIODE
STARTER MOTO
ENGINE GROUND
NEGATIVE BATTERY
MAIN FUSES
SECONDARY FUSES
LEFT REAR TURN INDICATOR
CURRENT PLUG
TILT SWITCH
DIODE-RESISTANCE MODULE MUST BE CONNECTED WITH DIODE HOUSING
DIODE 1N4007 WITH TRANSPARENT SHRINKABLE
RESISTANCE 220Ω /3 WATT WITH TRANSPARENT SHRINKABLE
THE SHAPE IN THIS DRAWING SHOWS: BLACK TAPE BIND L=xxxx
38602-94000 DETAIL VIEW OF STARTER MOTOR CAP:38602-94000
38601-94000 DETAIL VIEW OF 38601-94000 GROMMET FOR HARNESS POSITION
HARNESS:HRA 60-65
WIRING HARNESS
JC125T-17A
36600-94000
南京金城机械有限公司
NANJING JINCHENG MACHINERY CO., LTD